

### Notes

The following **Tech Update** highlights the process for updating the firmware on the **RVM2.0**.

### Step by Step Process

- 1) Copy the file jl\_690x.bfu to an empty USB flash/jump drive that is formatted to a FAT32
- 2) Turn vehicle on and turn radio on
- 3) Once radio has gone through boot up, plug USB jump drive in
- 4) The radio will display "UPDATE" and will shut off after a few seconds (When radio shuts off, the firmware has been installed)
- 5) With radio off, remove the USB flash/jump drive and disconnect the B+ wire (Yellow) and ACC wire (Red) from the back of the radio
- 6) Reconnect the B+ wire (Yellow) and the ACC wire (Red) on the back of the radio then turn radio on
- 7) Press "MODE" button to "AUX IN 1" source then press and hold the ">>" button for 5 seconds and "RESET" will be displayed (the firmware installation is complete)
- 8) To confirm that the new firmware has been installed, press "MODE" button to "AUX IN 1" source (press and hold "1" button for 2 seconds and will show the software version)
- 9) If it is "200616U1," then the latest version has been installed